


# Dimension Guide

## Washer and washer dryer

**Model:**

EWF7524CDWA

EWW7524ADWA



\*Add 20mm for the hose protrusion at the back.

**IMPORTANT**

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

© 2019 Electrolux Home Products Pty Ltd. EDIM\_Washer\_WasherDryer\_Jan19